

Wall Button

When used in conjunction with the Cellular Base Station and/or Mobile Device, the Wall Button allows you to obtain emergency help with the press of a button. The Wall Button can be mounted on a flat surface such as a wall or placed on a table top. Mounting hardware and two-sided tape is included. The Wall Button includes 2 AAA batteries that are easy to replace. The Wall Button has an LED Light that will communicate the following:

Light Indicator	What it Means
● RED	When you press your emergency Wall Button, the LED light will flash red.
☀ AMBER	When the battery level is low, the LED light will blink amber.

Please Note: Unlike your standard Neck Pendant and Wrist Buttons, this Wall Button is not waterproof.

